

# Operating Instructions

## Tube assembling

### Tube assembling on Connector Interfaces

The fixing nose-pieces are arranged in pairs in a row. The corrugated tube must be laid over both fixing nose-pieces. Slit tubes may not be twisted.

- 1 The corrugated tube must tower above the catches approx.  $1\frac{1}{2}$  -  $2\frac{1}{2}$  crests to guarantee ideal fixation.



- 2 Plug engage.



- 3 Closing connector interface.



## Tube assembling on Connector Interfaces + Plugs

### Connector Interface with installing counterpiece (plug)



- 1 Hook the plug in the intended land and mount the corrugated tube.  
**Mind the correct nominal width of the corrugated tube.**

- 2 Make sure that the locking mechanism of the plug is inserted in the designed notch. Lay the half shell of the plug around the corrugated tube.



- 3 Put pressure on the catches of one side of the connector interface until they snap in perfectly. Put pressure on the catches of the opposite side of the connector interface until they snap in perfectly.



**The Schlemmer Group** is a global technology expert, which has focused on the development and production of industrial solutions, including the area of sensitive electrical installations. Drawing on 60 years of experience in cable protection, the

Group has evolved into a leading and comprehensive value added supplier. In addition to the traditional business segment Automotive, the Schlemmer Group operates in numerous other industries with its business segments Industry and Appliances.

#### Any questions left?

Visit our website at  
[www.schlemmer.com](http://www.schlemmer.com)  
or write us an e-mail at  
[info@schlemmer.com](mailto:info@schlemmer.com)

